

Cabinet Installation



**Your Style
With Our Solutions
Creates Home**

CANYON CREEK
Cabinet Company

Canyon Creek offers framed and full access premium cabinet lines; a value frame-less line and Closets Plus for all of your storage needs.

Our standard design options and custom capabilities provide the flexibility to design within any budget. You can order it all with fixed lead times of as little as four weeks...

Canyon Creek Cabinet Company
16726 Tye St SE
Monroe, WA 98272

P: 800-228-1830
F: 800-787-0131

www.canyoncreek.com

Once you have your new Canyon Creek cabinets, we suggest that you use a qualified, experienced installer who is licensed and bonded. The correct cabinet installation is the final step to your cabinet purchase, and a quality installation is essential to ensure your complete satisfaction.

The following steps are what you can expect when you have your cabinets installed. Due to job site conditions and the individual installer's techniques, variations on the following guidelines may be necessary and are permissible with a reputable installer.

Room Inspection & Preparation

For new construction, all rooms should be cleared of debris. Plumbing, wiring and other mechanical "rough-in" should be completed. The installer needs to verify that all the plumbing fixtures, vents and pipes are where they should be located in relationship to the plans.

If you are remodeling your kitchen, make sure that all existing appliances, sinks and unnecessary fixtures are removed. Kitchen walls and ceilings must be free of all obstructions. Old cabinets, baseboards, wainscoting and other items affecting the installation should be removed.

Any painting, electrical or plumbing that you have planned should be completed before your new cabinets are installed. It is also important to protect any new flooring with cardboard or tarps during cabinet installation.



Basic Tools Required

- Level
- Shims
- Carpenter's glue
- C-clamps
- Crosscut fine tooth hand saw or chop saw
- Fasteners – wood or sheet metal screws
- Screwdriver – slotted and Phillips
- Touch-up pens & putty stick to match finish
- Tape measure
- Nail gun or hammer
- Electric drill and drill bits
- Carpenter's square



